

ROCTEX Handling & Storage Instructions

To Unload panels from the crate or skid follow these steps:

- Lift only one side of the panel slowly with the other edge of the panel resting on the crate/flat surface.
- Lift it off the crate/flat surface, put a hand underneath and carry with the profile placed vertically (Figure 1).
- To put the panel on the ground, let it rest on the long edge first and slowly put it on the ground.
- Always keep the panel upright or on its edge when carrying to avoid breakage or cracking
- Never carry the panel flat, it will snap in the middle.

Figure 1 - put a hand underneath a panel and carry with the profile placed vertically.



Storage:

ROCTEX panels need to be stored on a flat surface in the dry area. Stacking is allowed however no more than 8-10 panels at the time should be stored (profile dependent). Sheets of polystyrene or protective foam should be placed between panels. These are provided in the crate or skid.

Cleaning:

For general care and maintenance most spills or marks can be cleaned using a white damp cloth water or mild detergents.

Do not use coloured rags or solvent-based cleaners.

Ph: 02 9833 1157
sales@roctex.com.au
www.roctex.com.au